

Installation Instructions 2A Aluminium Two Hole Cable Clamp

 Position the cable clamp and 2 bolts (not supplied) onto the support structure. 2A Clamp



2) Install the cable.



 Locate the other half of the cable clamp. Secure with 2 fastening nuts and washers (not supplied) and tighten.



4) **Important.** Do not over tighten the cleat. The cleat should secure the cable but does not need to be so tight that the cable bulges at either side of the cleat.



Issue 01 02/05/13

Ellis Patents Ltd High Street, Rillington, Malton, North Yorkshire YO17 8LA United Kingdom T. +44 (0)1944 758395 F. +44 (0)1944 758808 sales@ellispatents.co.uk www.ellispatents.co.uk